

**Прайс на заправку та відновлення картриджів**

Модель апарату	Модель картриджа	Заправка	Заміна запчастин				
		Ціна, грн	Фотобарабан	Ракель	Магнітний вал	Вал перв. заряду	Лезо дозування
HP LaserJet 1000; 1005	HP 15A (C7115A)	100	67	45	68	53	45
HP LaserJet P1005; P1006; P1007; P1008; P1009	HP 35A (CB435A)	100	67	45	68	53	45
HP LaserJet 1010; 1012; 1015; 1018; 1020; 1022	HP 12A (Q2612A)	100	67	45	68	53	45
HP LaserJet 1100	HP 92A (C4092A)	100	67	45	68	53	45
HP LaserJet M1120 МФУ; P1505	HP 36A (CB436A)	100	67	45	68	53	45
HP LaserJet 1160	HP 49A (Q5949A)	100	67	45	68	53	45
HP LaserJet 1200; 1220; 3300; 3310; 3320; 3330; 3380; 3390	HP 15A (C7115A)	100	67	45	68	53	45
	HP 15X (C7115X)	140	67	45	68	53	45
HP LaserJet 1300	HP 13A (Q2613A)	100	67	45	68	53	45
HP LaserJet 2200	HP 96A (C4096A)	100	67	45	68	53	45
HP Color LaserJet CM1312 МФУ; CP1215; CP1217; CP1514; CP1515; CP1518	HP 125A Black	320+чип	129	114	105	135	106
	HP 125A Yellow	320+чип	129	114	105	135	106
	HP 125A Magenta	320+чип	129	114	105	135	106
	HP 125A Cyan	320+чип	129	114	105	135	106
LaserJet P2035, P2055d, 2055dn	HP 05A (CE505A)	100	98	45	68	53	45
LaserJet P3015, P3015D, P3015DN, P3015X	HP 55A (CE255A)	140	204	45		117	45
HP LaserJet Pro M154; M180	HP 205A B/Y/M/C	320+чип	129	114	105	135	106
HP LaserJet Pro M176; M177	HP 130A B/Y/M/C	320+чип					
HP LaserJet Pro M252; M277	HP 201A B/Y/M/C	320+чип					
HP LaserJet Pro M254; M280; M281	HP 203A B/Y/M/C	320+чип	129	114	105	135	106
	HP 203X B/Y/M/C	320+чип	129	114	105	135	106
HP LaserJet Pro M476; 400 M451	HP 305A B/Y/M/C	320+чип	129	114	105	135	106
HP LaserJet Pro CP1025; MFP M275; 100 MFP M175	HP 126A B/Y/M/C	320+чип					
HP LaserJet Pro 400 MFP M425; M401	HP 80A	100	98	45	68	53	45
HP LaserJet Pro M102; MFP M130	HP 17A	120			336	225	168
HP LaserJet Pro M104; MFP M132	HP 18A	120			336	225	168
HP LaserJet Pro M201; MFP M125; MFP M126; MFP M127; MFP M128; MFP M225; MFP M226	HP 83A	100	67	45	68	53	45
HP LaserJet Pro MFP M225; MFP M226	HP 83X		67	45	68	53	45
HP LaserJet Pro M203; MFP M227	HP 30A	120					
	HP 30X						
HP LaserJet Pro M12A; MFP M26	HP 79A	100	67	45	68	53	45
HP LaserJet Pro P1102; P1106; P1108; MFP M1212; MFP M1213; MFP M1214; MFP M1216; MFP M1217; MFP M1219; MFP M1132; MFP M1136; MFP M1137; MFP M1138; MFP M1139	HP 85A (CE285A)	100	67	45	68	53	45
HP LaserJet Pro P1606; MFP M1536; MFP M1537; MFP M1538; MFP M1539	HP 78A (CE278A)	100	67	45	68	53	45
Canon LBP2900/3000	703	100	67	45	68	53	45
Canon MF6530, MF6540, MF6550, MF6560, MF6580	706	100	67	45	68	53	45
Canon i-SENSYS LBP3300, i-SENSYS LBP3360	708	100	67	45	68	53	45
	708H	160	67	45	68	53	45
Canon LBP3010, LBP3010B, LBP3100	712	100	67	45	68	53	45
Canon LBP-3250	713	100	67	45	68	53	45
Canon LBP-3310/3370	715	100	67	45	68	53	45
Canon LBP6300, LBP6310, LBP6650, LBP6670, LBP6680, MF5840, MF5880, MF5940, MF5980, MF6140, MF6180	719	100	67	45	68	53	45
	719H	140	98	45	68	53	45
Canon F-158200, LBP6000, LBP6020, LBP6030, MF3010	725	100	67	45	68	53	45
Canon LBP6200, LBP6230dw	726	100	67	45	68	53	45

Canon MF4410, MF4750, MF4870DN, Fax-L410, MF4430, MF4450, MF4550D, MF4570DN, MF4580DN, MF4730, MF4780WNE (Wi-Fi), Fax-L150, Fax-L170, MF4890dw	728	100	67	45	68	53	45
Canon LBP7018C, LBP7010C	729 B/Y/M/C	320+çin					
Canon LBP7100Cn / LBP7110Cw	731 B/Y/M/C	320+çin	129	114	105	135	106
Canon MF211, MF212W (Wi-Fi), MF216N, MF217W (Wi-Fi), MF226DN, MF229DW (Wi-Fi)	737	100	67	45	68	53	45
Canon LBP1120, LBP800, LBP810	EP-22	100	67	45	68	53	45
Canon LBP3200, LBP3210, MF3110, MF3200, MF3220, MF3228, MF3240, MF5600, MF5630, MF5650, MF5730, MF5750, MF5770	EP-27	100	67	45	68	53	45
Canon FC108, FC128, FC200/FC200S, FC204/FC204S, FC206, FC208, FC210, FC220/FC220S, FC224/FC224S, FC226, FC228, FC230, FC280, FC290, FC330, FC336, FC530, PC740, PC750, PC760, PC770, PC780, PC860, PC880, PC890	FC-E16	270					
L95, MF4010, MF4018, MF4120, MF4140, MF4150, MF4270, MF4320, MF4330, MF4340, MF4350, MF4370, MF4380, MF4660, MF4690, PC-D440, PC-D450	FX-10	100	67	45	68	53	45
Samsung Xpress M2022, M2022W, M2020, M2021, M2020W, M2021W, M2070, M2071, M2070W, M2071W, M2070F, M2071FH, M2070FW, M2071FH	MLT-D111S	130+çin	82	52	83	110	80
Samsung ML-2164, 2164W, SCX-3400, 3405	MLT-D101S	130+çin	82	52	83	110	80
Samsung ML-1665K, 1673, 1674, 1673 /DCS, 1865K, 1864K, 1861K, 1865K /DCS, 1865WK, 1865WK /EXP, SCX-3210K, 3205K, 3205 /HYP, 3210K /DCS, 3210WK	MLT-D104S	130+çin	82	52	104	117	58
Samsung CLP-320, 325, CLX-3185	CLT-Y407S Yellow	320+çin					
	CLT-K407S Black	470+çin					
	CLT-C407S Cyan	320+çin					
	CLT-M407S Magenta	320+çin					
Samsung ML-3310D, ML-3310ND, ML-3710D, ML-3710ND, SCX-4833FD, SCX-4833FR, SCX-5637FR	MLT-D205L	130+çin	82				
Samsung SCX-4200	SCX-D4200A	130+çin	82	52	83	75	58
Samsung SCX-4300	MLT-D109S	130+çin	82	52	83	75	58
Samsung ML-1510, 1710, 1740, 1750	ML-1710D3	130+çin	82	52	83	75	58
Samsung ML-1210, 1220M, 1250, 1430	ML-1210D3	130+çin	82		83	75	58
Samsung SCX-4100	SCX-4100D3	130+çin	82	52	83	75	58
Samsung SCX-4650	MLT-D117S	130+çin	82	52		85	58
Samsung ML-1610/ 1615/ 1620/ 1625, ML-2010/ 2015/ 2020/ 2510/ 2570/ 2571, SCX-4321/ 4521	MLT-D119S	130+çin	82	52		85	58
Samsung ML-1660/1665, SCX-3200/3205	MLT-D104	130+çin	82	52	104	101	58
Samsung ML-1630 /1630W, SCX-4500/4500W	ML-D1630A	130+çin	82			85	
Samsung ML-1910/ 1915/ 2525/ SCX-4600/ 4623/ SF-650	MLT-D105	130+çin	82	52		85	58